



GENERAL

The Vanner ultra high power 1250GCP electronic flasher has been designed to operate in the most severe environments. This unit has output short circuit protection (patent applied) for reverse input voltage protection.

CHARACTERISTICS & TIPS

- 1) Under some load conditions this flasher may turn on for one flash when the main power is applied and the remote ground control switch is off. This is a normal condition that indicates that the flasher is operating properly.
- 2) For long reliable operation it is imperative that the flasher not be overloaded. In some cases the unit's short circuit protection might consider the overload a short circuit and shut the unit down.
- 3) The A output of the flasher receives its operating voltage from the B output. If the B output does not flash, then as a result the A output will not flash.

SPECIFICATIONS

Maximum output current: - with 50w lamps - with 35w lamps	50 Amps per terminal <i>9 typical per terminal</i> <i>12 typical per terminal</i>
Input Voltage:	10-16 Vdc, 13.6 Vdc nominal
Flashes per min. over full voltage range:	60 ± 8%
Duty cycle:	50/50 ± 10%
Ambient temperature:	-40°F to 150°F

TROUBLESHOOTING

PROBLEM	ITEMS TO CHECK
All outputs do not flash:	<ol style="list-style-type: none"> 1) Is the battery voltage less than 10Vdc? 2) Do you have more than the rated number of lights on the outputs? 3) Is the remote ground control switch wired correctly?
One output does not flash:	<ol style="list-style-type: none"> 1) Is the battery voltage less than 10 Vdc? 2) Is the affected output shorted or overloaded?
The flasher flashes once when 12 Vdc is applied and the ground control switch is off:	<ol style="list-style-type: none"> 1) This is normal operation under light loads.

* If after reviewing this chart you still can't locate the problem contact Vanner for technical assistance—800-AC POWER

